



# Twin Bod 2.0

Wireless Earbuds  
with Speaker



**Model No.: iG-1032**

## Highlights

- Bluetooth
- Speakerphone + Earphone
- Rechargeable Battery

## Package Contents

- Wireless Earbud
- Charging case with speaker
- Eartips
- Micro USB charging cable
- Handel strap
- Instruction manual

## Specifications

- Bluetooth
  - Version: 5.0
  - Chipset: Bluetrum
  - Profiles: A2DHFP, HSP, AVRCP
  - Distance: Up to 32.808 ft / 10 m
- Frequency Response: 90 Hz – 20 kHz
- Signal to Noise Ratio: 80 dB
- Charge Input: DC 5V, 1A
- Speaker driver: 3W

- Earbuds Battery Capacity: 45 mAh, Rechargeable Battery
- Charging case capacity: 400 mAh, Rechargeable Battery
- Charge time for earphone: 1.5 Hours
- Charge time for charging case: 3-4 Hours
- Playtime (earphone): 3 Hours
- Playtime(speaker): 4-5 Hours

## How to use

### 1. To charge charging case

- a. Please fully charge the earphone and charging case before using it for the first time.
- b. Connect the USB a end of the charging cable to a USB charging port and insert the micro USB end to the port on the charging case. Make sure it is properly connected.
- c. The indicator light will flash RED while the charging case is on charge. Depending on the power delivered to the charging case, the charging case will take approximately 2 hours or more to charge completely.

- d. The indicator light will go solid red when the case is fully charged.

## **2. To charge earphones**

- a. Put the earphones into the charging case to charge it. The red light on the earphone and blue light on the charging case will indicate the charging process is live.
- b. When the earphones battery is full, the red indicator light will switch off.

Note: Please fully charge the earphone and charging case before using it for first time.

## **3. Power on**

Take out one of the earpiece from the charging case. Earphones will automatically turn on with a voice prompt: "POWER ON" or Press and hold the multi-function key on either of the earphones for 3 seconds. Release when the red indicator light is on with a voice prompt: "POWER ON"

## **4. Pairing**

- a. When Powered on, two earphones will connect each other automatically. It will prompt "Pairing". The indicator light of one earphone will flash blue and red while blue indicator light of another earphone will flash slowly.

- b. When the earphones are connected with your device successfully, the indicator lights of two earphones will flash blue slowly.
- c. Activate the Bluetooth on your playback device and search for “iGear-Twinbod 2.0”. Select “iGear-Twinbod 2.0” from the device’s list to connect. You will hear a connection tone after the earphone has been paired successfully.
- d. Earphones will response with a voice prompt: “DISCONNECTED” when Bluetooth signal is cut off, and will shutdown 5mins later automatically.
- e. When powered on, the earphones will connect the last paired mobile automatically.
- f. You can now playback audio through the earphone.
- g. Volume can be controlled on your playback device (smart phone, computer, tablet, etc.).
- h. Music tracks can be selected on your playback device (smart phone, computer, tablet, etc.).

Note: If you see 2 PAIRING NAME entries in available devices then the earphones are not paired correctly. Please follow below steps to get it paired correctly:

\*Please make sure that both earphones are switched off before putting them in the charging case. If they are not paired or reset to defaults, you need to pair 2 earphones manually as below steps:

- Press and hold the multi-function key for 5 seconds of both earphones simultaneously, release when the indicator lights turn red and blue, and responds with a voice prompt: "POWER ON", it will then pair and connect automatically.
- When paired successfully, the indicator lights of one earphone will flash alternately in blue and red, while blue indicator light of another earphone will flash slowly.

## **5. Speaker + Earphone mode**

If earphones are put into the charging case when listening music, it will play by speaker automatically and earphones will start charging automatically.

## **6. Power off**

- a. TWS mode: Press and hold the multi-function key on both earphone for 5 seconds. Release when the red indicator light is on with a voice prompt: "POWER OFF".

- b. For independent use mode (Single Ear): Press and hold the multi-function key on the earphone for 3 seconds. Release when the red indicator light turns on with a voice prompt: "POWER OFF".
- d. The battery status of earphone is visible on connected devices. When it will run out of power, the earphone will remind you with a voice prompt: "PLEASE CHARGE".

## **7. Single ear for independent use**

- a. Press and hold the multi-function key for 5 seconds on either earphones (based on your personal preference), release when the red and blue light flash's alternately.
- b. Enable your phone's Bluetooth pairing function and search for the "iGear-Twinbod 2.0" to pair and connect.

## **8. Phone & Music**

- To answer a call  
Short-press the multi-function key of either earphones.
- To end a call  
Short- press the multi-function key of either earphones.

- To reject a call  
Press and hold the multi-function key of either earphones for 5 seconds.
- To Re-dial a call  
Press the multi-function key of either earphones three times.
- To Play and Pause Music  
Short-press the multi-function key on either earphone.
- To Play the next song or Previous song  
Press the multi-function key on either earphones twice.

## **Locating the Bluetooth menu**

### **iPhone, iPad, and iPod Touch**

- a. On your device, go to Settings.
- b. Select Bluetooth. If Bluetooth is not on, turn it on.
- c. The iPhone / iPad / iPod will automatically search for new devices.

### **Android™ Phones and tablets**

- a. On your device, go to the Settings Menu
- b. Select Bluetooth (on older Android devices, Bluetooth is found in the Wireless & Networks menu). If Bluetooth is not on, turn it on.



- c. Select “Search for devices” if your phone or tablet does not automatically search for new devices.

**Note:** If you are unsure of how to access your Bluetooth menu on your device, please refer to your device’s instruction manual.

## **Safety Precautions**

Please read, follow and keep these instructions:

- a. Keep the device out of extreme heat and humidity.
- b. Power time may differ depending on personal habits.
- c. Heed all warnings on the product and in the operation instructions.
- d. Avoid listening at high volume level for long period.
- e. Stop using this product immediately if it causes discomfort or pain.



**Imported and Marketed By:**

iGear Tech Pvt. Ltd.

204, Sai Corporate Park, Laxmi Nagar, Off Link  
Road, Goregaon West, Mumbai - 400104.

Country of Origin: PRC

Name of Commodity: Twinbod 2.0(iG-1032)

Month and Year of Import: April, 2020

Net Weight: 104gms

Net Quantity: 1 unit

Charging case Dimensions: 36.3mmx95.5mm

Earphone Dimensions: 29mmx17.2mmx20.8mm

Voltage: DC 5V

Speaker Wattage: 3W

Earphone Wattage: Ø8W

Warranty Period: 1 Year

In case of consumer complaints:

Toll free number - 1800 22 8495,

Email: sales@igear.asia

(Between 10am to 5pm, Mon- Fri)