

**EUREKA FORBES**  
Your friend for life



**FORBES**  
Clean Home. Healthy Family.



***Super Clean*** Vacuum Cleaner



OWNERS MANUAL

Dear Customer,

Congratulations on your choice of cleaning help and welcome to the happy family of over 5 million satisfied owners of Eureka Forbes Vacuum Cleaners.

We always endeavour to bring to you technologically superior appliances, designed to let you live life on your terms.

Forbes Super Clean, a multi-purpose, power-packed, daily use vacuum cleaner gives you immense cleaning power. Its high suction and amazingly low power consumption makes it an ideal cleaning device.

To always ensure the optimal functioning and performance of your product, we would like to advise the following:

- 1) Before using the appliance for the first time, carefully read the operating and safety instructions and adhere to these at all times.
- 2) In case you pass on this product to someone else, please ensure that you hand over the user manual along with it.

Should you have any further question, visit [www.eurekaforbes.com](http://www.eurekaforbes.com) or for any assistance you can be rest assured that we are just a call away.

- 3) Detailed instructions are available in the CD as well as on our website..

Happy Cleaning.





## PRODUCT DESCRIPTION



1.DUST CUP 2. SUCTION END 3.SHOULDER STRAP EYELET 4. HANDLE 5.ON/OFF BUTTON 6.DUST CUP RELEASE BUTTON 7. BLOWER END 8. CREVICE NOZZLE 9. FLEXIBLE HOSE 10. FLOOR BRUSH 11. BLOWER ADAPTOR 12. MULTI-PURPOSE BRUSH 13. SHOUDER STRAP 14. TUBES 15. INFLATOR


## GETTING STARTED

Note!


Always disconnect the plug from socket before opening the dust compartment

Remarks


To open the dust compartment (1), push the release button (6), and pull back the dust compartment (1).




To attach the crevice Nozzle , simply push it into the suction port ,as shown in the diagram below:




To use upholstery Nozzle , hose , simply plug the hose into the suction port ,then nozzle connected to hose ,as shown in the below diagram :



To use the floor brush , hose , , simply plug the hose into the suction port ,then two tubes connected to hose ,floor brush connected to tubes ,as shown in the below diagram :



To use the blow function , pls plug the adaptor to machine end ,then connected the hose set ,as shown in the below diagram



## TROUBLE SHOOTING GUIDE

Problem	Possible cause	Suggested remedy
The vacuum cleaner wont start	Not plugged in properly. No power supply to the wall socket	Plug in properly Check the fuses
Poor /no suction	Dust filter is full	Empty and clean the filter
	The vacuum is clogged	Turn off the vacuum cleaner and pull out the plug, remove the filter and check if something blocking the hose or nozzle
Dust is escaping from the vacuum cleaner	Dust filter is full	Empty and clean the filter
	The filter is not fitted correctly	Read the instruction and fit it correctly
	There is a hole in the filter	Change the filter
Neither the nozzle nor the brush sucks anything up	The vacuum hose is clogged	Disconnect the hose and remove the obstructions
	Dust filter is full	Empty and clean the filter
The vacuum cleaner stops working after using it for some time	Motor is overheated, the thermostat start to work and cut off the power to protect the motor	Plug out, clean the filter, let the vacuum cleaner cool down

## SPECIFICATION

Main supply : 230v 50hz

Power : 800w

Power cord : 5.0 m

## SAFETY

- Warning! Do not open the casing ! Certain components within the product's casing contain dangerous current. Contact these may cause an electric shock
- The product should only be repaired by qualified service personnel
- The product should not be taken apart or modified
- Do not place the product where it could be exposed to water or other liquid ,An electric appliances which is connected to a wall socket is still live even when not in use
- Do not obstruct the air vents with curtains or tablecloths etc

**WARNING: TO AVOID THE RISK OF FIRE, ELECTRIC SHOCK OR PERSONAL INJURY, BELOW ATTENTIONS:**

- The vacuum cleaner should only be used as described in the manual. Only use accessories recommended by the manufacturer
- Do not expose the vacuum cleaner or its power cord to moisture, blows or high temperatures.
- Do not use the vacuum cleaner if its power cord or plug is damaged. Neither should you use it if you have dropped it on the floor, left it outdoors or dropped it in water.
- Do not leave the vacuum cleaner unattended when it is connected to a power socket. Pull the plug out when the vacuum cleaner is not in use.
- Do not pull or carry the vacuum cleaner by the power cord. Do not use the power cord as a handle and do not let it fasten in a door. Do not pull the power cord around sharp corners and edges.
- Do not insert anything into any opening other than the suction port. Do not vacuum if any opening is clogged. Keep all air intakes free from dust, fluff, hair and anything that can reduce the airflow.
- Do not vacuum anything that is smoking or burning, such as cigarettes, hot ashes etc. Do not vacuum flammable liquids such as petrol.
- Do not vacuum if the dust filter is not in place.
- Only use the vacuum cleaner on dry surfaces indoors. Store the vacuum cleaner indoors. Do not vacuum outdoors or on wet surfaces.
- If the vacuum cleaner is damaged, it must be repaired. Contact our Customer Services Department (address on back cover).
- If the power cord is damaged, it must be replaced by the manufacturer or its service agent or a qualified person in order to avoid a hazard.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

## Aeroguard Range of Air Purifiers



**BREEZE**  
MRP ₹12999/-



**FRESH**  
MRP ₹4999/-



**MIST**  
MRP ₹17999/-

## Aquaguard Range of Water Purifiers



**Crystal Plus**  
MRP ₹8999/-



**Superb**  
RO+UV+UF  
MRP ₹19999/-



**Geneus**  
MRP ₹22990/-



Marketed and Serviced By:

**EUREKA FORBES LIMITED**

B-1/B-2, 701, 7th Floor, Marathon Innova, Marathon NextGen, Off Ganapatrao Kadam Marg, Lower Parel, Mumbai-400 013.

Tel: 022 30449700, 30449888 Fax: 022 30449701, [www.eurekaforbes.com](http://www.eurekaforbes.com)