AMBRANE



MULTI-PURPOSE GROOMING KIT

FOR BEARD, HAIR & BODY GROOMING

CRUISER MINI

USER MANUAL

Thank you for choosing the **Cruiser Mini Grooming Kit**. Before using the product, please read the manual carefully and follow the instructions to operate properly.

PRODUCT OVERVIEW



- 1. Toggle Power On/ Off switch
- 2. Battery Indicator
- 3. Hair Trimmer
- 4. Body Groomer
- 5. Comb for Hair Trimmer (4,6 & 8 mm) 13. Oil
- 6.3mm comb for Body Groomer
- 7. 6mm comb for Body Groomer
- 8. 9mm comb for Body Groomer
- 9. 12mm comb for Body Groomer
- 10. Rotating comb for 0.5 10 mm

trimming (For Beard Trimming)

- 11. Big comb with 13/15/17/19/
- 21/23 mm for trimming
- 12. Brush
-
- 14. USB cable
- 15.Storage Stand
- **i 3.**Storage Stana
- 16. Adjustable Big Comb

OPERATING INSTRUCTIONS

Note: Before using it, make sure it is completely charged.

Connect USB side of the charging cable to your regular adaptor (5V/1A) and plug-in the other side at the bottom of trimmer. While charging, the indicator will light up in red colour. The charging time is 2 hours and when fully charged, it can be used for about 60 mins.

Push the switch button to ON to turn on the trimmer.

HOW TO USE COMBS ATTACHMENTS

On Hair Trimmer:

1. Comb installation: Install the comb along two sides of the hair trimmers head and make sure at the time of installation trimmer is in switch OFF mode.



2.Manually push the comb and adjust the gear, there are 5 gears as options.



On Body Groomer:

1. Make sure the groomer is in OFF state before changing the combs. There are four comb attachments of 3,6,9 &12mm respectively for different length cutting.



2. Push the comb button as shown in the picture:



Maintenance of the blades:



Using the brush, clean the blade in order to remove hair which may be caught between the blades. Lubricate the space between the stationary and moving blades with 2 or 4 drops of oil after every few uses.

To reassemble, push the blades until they click firmly into position.



How to use the toggle Button:

Push the toggle Button up or down to adjust the moving blade part for different lengths cutting. It can only be used with the hair trimmer or body groomer.

PRODUCT SPECIFICATIONS

Motor Voltage: DC5V

Voltage: 5V/1000mA

• Battery Capacity: 600mAh

• Charging Time: 2 Hours

• Run Time: 60 Mins

• Cell Type: Lithium Cell

CAUTIONS

- Don't use it while charging.
- Don't charge if the temperature is lower than 0° C or higher than 40° C.
- · Don't keep it in sunlight.
- Clean the trimmer with a cloth dampened with water or a mild soap solution. Never use a caustic solution.
- Never submer
- It may get hot during operation and/or charging which is quite normal.
- old the charging cable.
- Make sure to charge it at least once in a year to keep the battery in active condition.

PLEASE NOTE

This product is not intended for use by persons (including children) with reduced physical, sensory of mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety; Children should be supervised to ensure that they do not play with the product.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, such as the unused batteries and motors etc. recycle them responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

SAFETY WARNING

- For your continued safety and to reduce the risk of injury or electric shock, please follow all the safety precautions listed below.
- This product can be used by aged from 18 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved. Children shall not use or play with the product.
- Cleaning and maintenance shall not be done by children without supervision.
- Never pull the charger cable to unplug the product.
- Always check the blades for alignment before use.
- The product can become hot during use, use it for a maximum of 30 minutes and then allow it to cool for 30 minutes.
- The product is only intended for clipping human hairs. Do not use this plug for any other purpose.
- · Not to be used in bath or shower.
- Always check the product for damage prior to use. If any damage is observed, do not use the product.
- This product and charger have no user serviceable parts. Do not attempt to access the product covers.
- This product is for personal use only. It is not suitable for commercial use.
- Do not place the product on or near a heat sensitive surface.
- · Keep the product dry.
- Do not use the product or handle the charger with wet hands.

WARRANTY CARD AND TERM & CONDITIONS

NOTE: To Claim the warranty, all information on the warranty certificate should be completed along with original invoice.

- All warranty information, product features and specifications are subject to change without prior notice.
- · All matters are subject to Delhi Jurisdiction.

Customer's Name			Contact Number
Customer's Address			
Model No.			
Name of Distributors Dealers		s/	Contact Number
Address			
Purchase Date			Invoice Number
Dealer's Stamp			

- Cruiser Mini Grooming Kit comes with 365 days warranty from the date of purchase.
- Warranty can not be claimed if the product is damaged by wrong operation or force majeure.
- Accessories supplied with the trimmer are not covered under the warranty.

Address: AMBRANE INDIA PVT_ITD

Plot No. 438, Sector-53, Phase 3, EPIP, HSIIDC Industrial Estate Kundli, Sonipat - 131028, Haryana, India

In case of complaint contact customer service for sales/service support:

Contact No.: +91-8929700222

Web: www.ambraneindia.com, E-mail: care@ambraneindia.com