


## Operation Method



### Light Mode

 Flame lamp On/Off switch, quick press to Start or Stop the lamp.

### Bluetooth Speaker Mode

 **Power On/Off Button:**  
Long press for 3 seconds to start the speaker, the white indication light will start blinking and you will hear the indication tune. Search for **iGear Cosmic** in your bluetooth menu. Once the speaker is paired with your device, you will hear a beeping sound and the white indication light will stay on continuously. Short press the button to Play/Pause.

 **Next Track:**  
Short press the button to go to next track.

 **Previous Track:**  
Short press the button to go to previous track.

 **Volume Increase Button:**  
Long press to increase the volume  
(when reach maximum volume, the speaker will say "di di").


 **Volume Decrease Button:**  
Long Press to decrease the volume.

### Timer Mode

 **Timer Mode:**  
Long press the button to turn on or off the timer function. The indicator light will stay on when the timer function is started. In the timer function mode, the flame lamp will stay on for 5 hours and then stay off for 19 hours and start again for 5 hours on a rotation basis till the battery is discharged.

## Charging Instruction

**Power Input:**  
Insert the USB cable into the port, when the product is charging, red LED will stay on. Once the charging is completed the LED will go off.



### Attention

1. Please charge the product in ambient temperature ranging from 0°C-40°C.
2. Not recommended for charging while using.
3. Please pull off the USB cable after full charge.
4. Please do not charge the product in high humidity environment.
5. The rechargeable lithium battery is built in to the product and cannot be removed or replaced.
6. Please charge the product once every month when not in use.
7. Please do not damage the mainframe.
8. Please do not use benzene, diluent and other chemicals to clean the surface.
9. Please do not place it close to magnetic and electric field.
10. Please avoid keeping it under direct sunlight or near heating appliances.
11. Please do not repair, disassemble, transform the product by yourself.

## Technical Parameters

Bluetooth Version	V4.2
Bluetooth Name	iGear Cosmic
Bluetooth Transmission Distance	≤10M
Output Power	10W
Speaker Parameters	∅ 52MM 4Ω8W
Number of LED	120pcs
Distortion Rate	≤10%
SNR	>75dB
Power Supply	5V 1A
Built-in High Efficiency Lithium Battery	3.7V 3600mAh



Imported and Marketed By:  
IGear Tech Pvt. Ltd.  
204, Sai Corporate Park,  
Laxmi Nagar, Off Link Road,  
Goregaon West, Mumbai - 400104.  
In case of consumer complaints:  
Toll free number - 1800 22 8495  
Email: sales@igear.asia  
(Between 10am to 5pm, Mon- Fri)

Premium Series



# Cosmic

Ambient Light & Speaker



Model No.: iG-1023