

Instruction Manual & Warranty Card



Preethi Kitchen Appliances Pvt. Ltd.

Established in 1978

9 Million Customers

70 Customer Care Centres

400 Authorised Service Centres


Over 7000 Dealers

Exports to Middle East, Far East, Singapore and Sri Lanka

Table of contents:

Contents	Page No
1. Know Your Blue Leaf Platinum	3
2. How to use Blue Leaf Platinum	4
3. Jars & Blade usage	4
4. Grinding Instruction	5
5. Super Extractor	6
6. Grind n' Store	7
7. Do's and Don`t	8
8. Auto overload Protector	9
9. How to use your Flexilid	9
10. Technical Specifications	10
11. Warranty Card	11-12
12. Notes	13
13. Customer Care Centres	14-15

Know Your Preethi Blue Leaf Platinum




Blades for 1.7 litre Jar




Dry & Wet Grinding Blade






Hold Jar Coupler and fix required Blade onto the Spindle by gently screwing down in an anti-clockwise direction with the Spanner provided on the Stirrer, until it is firm. DO NOT OVER TIGHTEN.

1.5 Litre Super Extractor



Grind n' Store



Body and Top Cap

1. Clean Body and Top Cap with a dump cloth and wipe dry.

Cleaning

2. Do not use abrasives or water for cleaning.

Stainless Steel Jars and Blades

- 1. Fill in ½ litre of water and a teaspoon of any mild cleaning powder.
- 2. Run the Mixie on Speed 1 for 30 seconds. leaving the Blade fixed to the Spindle of the Stainless Steel Jar.
- 3. Rinse and dry.
- 4. Always store Jars in inverted position to allow water to drain off.

Note:

JAR SEATING Seat Jar on the Top Cap, ensuring that the locks fit properly in the Grooves of the Top Cap.

DOME Ensure that the Dome Gasket is properly fitted and hold Dome gently while operating.

SPEED CONTROL: Turn Rotary Switch clockwise for Speed 1,2 or 3 as desired Turn Rotary Switch anti-clockwise for a few second and release for

momentary operation. (Inching is especially useful for wet grinding of chutneys, mincing meat, grating vegitables, crushing ice, etc.)

How to use your Preethi Blue Leaf Platinum

PREETHI is provided with PVC insulated 3 Core, Flexicord with 10 amps Plugtop & earthing. Plug the Power Cord to a 110 Volts AC supply only.

Jars & Blades Usage Description

Dry & Wet Grinding Blade	Mincer / Grater Blade	Whipper Blade



GRINDING INSTRUCTIONS

ROASTED CEREALS, RAW RICE, DAL, CHILLI
POWDER, GARAM MASALA, DHANIYA JEERA POWDER,
CURRY LEAF POWDER, COFFEE POWDER,
SAMBAR/RASAM POWDER....

- 1. Ensure Blade, Jar, Lid and ingredients are totally dry.
- 2. Run on Speed 3.
- 3. If you need finer powder, wait for 1 minute and grind again for 1 to 2 minutes.

IDLI, DOSA, UTHAPPAM, APPAM, PESARATTU, VADAI...

- 1. Soak Rice/Dal for 4 to 5 hours as required.
- 2. Drain water from ingredients.
- 3. Run on Speed 3 adding water gradually through Dome Lid.
- 4. If Material sticks to the sides of the Jar, stop and stir using Stirrer, run again.
- 5. Ensure free circulation by adding enough water.
- 6. Do not allow batter to get heated up.
- 7. Do not add too much water, where thick paste is required.
- 8. Grind twice if quantity is more.

Note: While wet grinding tough batter, air bubbles may enter the paste. This will result in the blade rotating freely and an increase in noise. If so, stop, stir the paste and restart.



- 1. Inch 5 to 7 times to powder ingredients.
- 2. Then add water as required.
- 3. Grind on Speed 3 (Speed 1 when using Grind n' Store).




MEAT MINCING, VEGETABLE GRATING, ICE CRUSHING...

- 1. Trim fat from meat and remove all bones.
- 2. Cut meat into 1" cubes.
- 3. Fill upto blade level only.
- 4. Inch 10 to 20 times or till material is minced/grated.
- 5. Repeat if quantity is more.




Noto:

- 1. Use the Mincer Blade for mincing operation only.
- 2. Operate in 'Pulse' mode only when using the Mincer Blade.



- 1. The Juicer Blade and Filter should be used for extraction and juicing.
- 2. The Whipper Blade can be used only for whipping / churning.
- 3. For whipping/churning run on Speed 1 only.





HOW TO USE SUPER EXTRACTOR

Align Filter grip to Jar Nose and lock Filter onto the Jar by turning clockwise. (If you are making fruit cocktail, you can put in different fruits, viz, apple, pineapple, mint leaves, sugar, lemon juice together).

Figure 2 Put ingredients into Filter.

Place Cup and close Lid firmly ensuring that the Lid nose slips into the Jar nose as shown in the picture. Seat Jar Assembly on Top Cap ensuring that the Jar Base locks fit properly in the grooves of the Top Cap.

Figure 4 Inch 7 to 10 times till ingredients are shredded.

Open Lid, remove Cup, add required water, replace Cup, close Lid and run on Speed 3.

Second extraction is possible for coconut milk (For tamarind extract, remove seeds before extraction).

Remove Jar Assembly from Mixie by turning the Jar anti-clockwise and lifting the Jar off the Top Cap. Pour juice from the Jar (the pulp stays in the Filter).

Note: For butter churning, egg whipping, lassi... use Whipper Blade without Filter.



Grind n' Store

Grind & Store Chutneys, Spices, Coffee Powder...

Separate Jars for each Spice or Chutney.

Airtight Cap keeps contents fresh.

Refrigerate and use as Serving Bowl.

HOW TO USE YOUR GRIND N' STORE

Figure 1: Put ingredients to be ground into Jar.

Figure 2: Invert Base onto Jar and turn in clock-wise direction, till it is properly locked.

Figure 3: a. Seat Assembly on Top Cap ensuring that the Base Locks fit properly in the grooves of the Top Cap.

b. Inch 5 to 10 times.

c. Grind on Speed 1 only.

d. NEVER GRIND FOR MORE THAN 1 MINUTE CONTINUOUSLY. If you need to grind for more than 1 minute, STOP MIXIE FOR 1 MINUTE & THEN GRIND AGAIN.

If the appliance is run for more than 1 minute while dry grinding, the contents will get excessively hot and can cause the Jar to warp out of shape.

Figure 4: After grinding, remove Assembly from Mixie by holding the Base, twisting anticlockwise and lifting off the Top Cap.

Figure 5: Invert Assembly, hold the Jar with one hand and twist open anti-clockwise, to release the Jar.

Figure 6: Allow contents to cool and then twist the Cap clockwise on the Jar to seal airtight, ensuring that the 'O' Ring is in place.

Figure 7: The *Grind n' Store* can be used as a Chutney Grinder by using the Chutney Grinder Lid instead of the Jars.

Caution: 1. NEVER LEAVE BASE ALONE ON MIXER.

NEVER OPERATE UNLESS JAR IS PROPERLY LOCKED ON THE BASE.

WARNING: Improper use of appliance without locking Jar onto Base can cause serious injury.

















- When operating the Mixie for the first time or after long storage or when the Mixie has been shifted over a long distance, rotate the Motor Shaft by hand through the Motor Coupler, until the Motor Shaft rotates freely.
- 2. Unplug from power source before fixing, removing attachments and also while cleaning or when not in use.
- 3. Ensure that the locks of the Stainless Steel Jar are properly seated in the grooves provided inside the Top Cap.



- Do not touch moving parts, while operating Mixie.
- 2. Do not overload Mixie. When hot air emanates from the openings on the Top Cap, switch off the Motor and wait for 3 minutes, before re-starting.
- 3. Do not add solid ingredients, when the Motor is running.
- 4. Do not operate with damaged Power Cord.
- 5. Do not tamper or attempt to repair "Preethi" Mixie.
- 6. Do not grind hot ingredients in the Mixie.
- 7. Do not use the Mincer Blade for operations other than mincing.
- 8. Do not run the Mixie without Top Dome.
- 9. Do not seat the Jar when the Switch is in 'On" condition.
- 10. Never put your hand inside the Jar, Without switching off the mixie.

1. Do not run without locking Filter properly.

2. Do not pierce Filter with sharp objects while cleaning.

Super Extractor



Grind n' Store



- 1. Ensure Blade is fitted properly before running.
- 2. When using Filter always use with Cup.
- 3. For butter churning, egg whipping, lassi... use Whipper Blade without Filter.
- 1. Ensure that Base Locks fit in the Grooves of the Top Cap.
- 2. Ensure that 'O' Rings on the Base and the Cap are properly fitted.
- 3. Clean 'O' Rings of both Base and the Cap after use, by washing in water with mild detergent.
- 4. For frequently used items, reserve one Jar and Cap which will save the trouble of frequent washing and cleaning.

- 1. Never leave Base alone on Mixie.
- 2. Do not run unless Jar is securely seated on Base.
- Do not run for more than 1 minute continuously, otherwise the Jar can warp due to excessive heat.


In the event your Mixie needs further attention, take it to one of our Customer Care Centres.

AUTO OVERLOAD PROTECTOR

If the Mixie stops in usage due to operation of the

Overload Protector, then:

- 1. FIRST SWITCH OFF THE MIXIE.
- 2. Remove some material which is being ground from the Jar, to decrease the load.
- 3. Wait for 3 minutes.
- 4. Lift the Unit and press the RED KNOB projecting out of Bottom Plate.
- 5. Re-startthe Mixie.



FLEXILID





Converts your 1.75 Litre Jar to 1.25 Litre Jar

NOTE: Ensure that the gasket is fitted properly to the FlexiLid.

HOW TO USE YOUR FLEXILID

- Add the required quantity of the ingredient into the Jar.
- Place the FlexiLid onto the Jar, and press till it seats firmly on the Jar (Refer figure).
- Start grinding. Hold the FlexiLid firmly while grinding.

Technical Specifications

Model & No. : Platinum - MG 153

Voltage : 110V AC 60 Hz.

Power Consumption: 550 Watts

Insulation : Class F

Protection : Class 1

Rating : Ordinary Total rated ON time

30 minutes (max.),

Continuous ON for 5 minutes (max.)

and OFF for 2 minutes (min.),

Rest time 45 minutes

Motor : Universal 550 Watts High Power Motor.

No load speed 18,000 RPM (approx.)

With load speed 11,500 RPM (approx.)

Material of Body : A.B.S

Material of Jars : Stainless Steel & Polycarbonate

Material of Dome : Polycarbonate, P.P.

Blade Assemblies : Stainless Steel, Machine Ground and

Polished.

Speed Controls : Rotary Switch with 3 Speed and Incher.

Flex Cord : PVC insulated 3 Core, Flexicord with

10 amps Plugtop & earthing.

Country of Origin : India

Jar Capacity

		Rated Capacity			
Jar	Size	Dry	Wet	Liquidise	Whip
Big Jar	1.7 litre	0.7 litre	0.5 litre	1.0 litre	-
Big Jar with FlexiLid	1.2 litre	0.5 litre	0.4 litre	0.6 litre	-
Super Extractor	1.5 litre	-	-	0.7 litre	Min: 4 Eggs Max: 8 Eggs
Grind n' Store	0.4 litre	0.3 litre	0.2 litre	-	-

Minimum Capacity for all the above At least up to Blade level

Gross Weight : 7.0 kgs (approx.)

Size of Carton : 44 cm (L) x 24 cm (W) x 38 cm (H)

Warranty : 1 Years

In pursuance with our policy of continuous product improvement, specifications are subject to change without notice.

Preethi Blue Leaf Platinum Blue Leaf

Heavy Duty Mixer Grinder - MG 153

Warranty Card Date Sold: SI.No.: Purchaser's Name & Address: Dealer's Name & Address: Signature: Stamp: TERMS & CONDITIONS OF WARRANTY AND SERVICE POLICY 01. Retain the original sale bill and the Warranty Card, which should be shown to our

- Service Personnel for Scrutiny while sending your Mixie for service to our Authorised
- 02. The One Year Warranty does not cover damage to the Mixie due to mishandling, negligence, breakage or cracking of Polycarbonate Jars, Domes, Lids, Mixie Body and Cap and denting of Stainless Steel Jar.
- 03. All repairs within the One Year Warranty period (arising from manufacturing defects) will be done 'Free of Charge'. Our Customer care Centres will not charge you for components or labour.
- 04. Free service and replacement under warranty does not affect the expiry date of
- 05. For repairs after the expiry of the warranty period our Customer care Centre will levy a nominal charge on components replaced.
- 06. The Warranty is valid only in the country of purchase.
- 07. Defective components which are exchanged both under 'Chargeable' & 'Free of Charge' basis, become the property of the Company.
- 08. If the Mixie is tampered with or opened by any unauthorised person, the warranty
- 09. Warranty is void if the Mixie is used for any purpose other than domestic use.

Preethi Blue Leaf	Blue Leaf Platinum	SALE DETAILS	MG 153
Date Sold:	SI.No.:		
Purchaser's Nam	ne & Address(in BLOCK	(LETTERS):	
Dealer's Name &	Address:		
Signature:		Stamp:	
	(To be retained by the L	Dealer) 	
Preethi	Blue Leaf Platinum	SALE DETAILS	MG 153
Blue Leaf Date Sold:		O/ILL DLI/IILO	
		(LETTERS):	
Dealer's Name & Address:			
Signature:	(To be returned to us throu	Stamp:	

Service Record	
DATE	COMPLAINTS & REMARKS

To be retained by customer

VERY IMPORTANT:
THE ONE YEAR WARRANTY
IS VALID ONLY IN THE
COUNTRY OF PURCHASE

Dealer's Name & Address:	
Signature:	Stamp:
Designation:	

Postage will be paid by addressee

BUSINESS REPLY CARD

Permit No. BRP/58 Teynampet. No postage Stamp necessary if posted in India

Preethi Kitchen Appliances Pvt. Ltd.

Corporate Office: 3/140, I.T. Highway, Oggiam Thoraipakkam, Chennai - 600 097.

Notes:
-

Preethi Kitchen Appliances Pvt. Ltd.

Corporate Office: 3/140, I.T. Highway, Oggiam Thoraipakkam, Chennai - 600 097. Phone: 2496 0574, 2496 4477, Fax: 91 - 44 - 2496 0349, email: info@preethi.in, Website: www.preethi.in

CUSTOMER CARE CENTRES

Tamilnadu

19, Dhandapani street, T.Nagar, Chennai - 17. PH: 24347418, 24363366, ccctnagar@preethi.in

No. 10. Brindhavan Avenue. West Tambaram, Chennai - 600045. PH: 22261510, ccctambaram@preethi.in

New No. 287, Old No. 123, Ground floor Purasaivakkam high road. Kellys. Chennai - 600010. PH: 25321338, ccckellvs@preethi.in

New No: 92/1 Old No 224/1 1st floor N.M Road, Avadi. Chennai - 600054. PH: 26555387, cccavadi@preethi.in

No.78/B, Kuppuswami street, Padi, Chennai - 600050. PH: 26547787, cccpadi@preethi.in

Shop No: 1 Laxmi Theatre complex 1st floor, D.No: 26 officer's lane Vellore - 632001, PH: 0416-2215916. cccvellore@preethi.in

Shop No.51, S.G. Puram Main Road, Villupuram- 605602. PH: 04146-252233. cccvillupuram@preethi.in

No. 40 viveks complex, Mettu Street Kancheepuram - 631501. PH: 044-27230492, ccckancheepuram@preethi.in

No.167 Vanniyar madam, 1st Floor, car street. Thiruvanamalai - 606601. PH: 04175-254900, ccctvmalai@preethi.in

HIG-67, Avalapalli hudco, Bagalure road, Hosur - 635109, PH: 04344-649857. ccchosur@preethi.in

No.121. Ist Floor, Canteen Street. Puducherry - 605001. PH: 0413-2346383. cccpuducherry@preethi.in

104, West perumal maistry street Opp. Thangam Theater, Madurai- 625001. PH: 0452-2347386, ccmadurai@preethi.in

No.1A, Kailasapuram East Street Tirunelveli - 627002. PH: 0462-2501824. ccctirunelveli@preethi.in

1023/8, Thanga meenakshi complex, Kambam road. V.V.G store back side. Theni - 625531. PH: 04546-253603. ccctheni@preethi.in

No.11 E. Meenakshi puram 2nd Street East. Tuticorin - 2. PH: 0461-2333668, ccctuticorin@preethi.in

No 102/2 Pullalakottai Road, Virudhunagar - 626001. PH: 04562-420624 cccvirudhunagar@preethi.in

No: 150, I st floor, K.P.Road, Parvathipuram, Nagercoil - 629003. PH: 04652-234005 cccnagarcoil@preethi.in

No, B6, Meyyammai complex, 1st Floor sastri road, Thillai nagar, Trichy - 620018. PH: 0431-2751288, ccctrichy@preethi.in

Door no: 60/8A, St, Anne's Convent Complex, 1st floor, Melaputhur, Trichy - 620001. PH: 0431-2415181. ccctrichycnt@preethi.in

no 2, 70, Srinivasan pillai road, Thanjavur - 613001. PH: 04362-273565. ccctanjore@preethi.in

No: 18, Rajbuilding 1st floor, 64/65, Pattamangala street, Mayiladuthurai - 609001. PH: 04364-241202. cccmayavaram@preethi.in

No: 48/124, 1st floor, South car street, Chidambaram - 608001. PH: 04144-223256 cccchidambaram@preethi.in

K.P.M Complex, No. 27/14 Car street, 1st floor shop No. B&C. K.P.M Plaza. Salem - 636001. PH: 0427-2250578. cccsalem@preethi.in

NO. 5 L.G.B compound, V.G.S Mahal Opp. Dindigul - 624001. PH: 0451-2423060 cccdindigul@preethi.in

No.45 Garuda Nivas, Govindarajulu salai, Aruna No,2957,58/25, Basement Gulap plaza Nagar, Karaikudi- 630001. PH: 04565-236376 II Stage, MKK Road, Near Navaranga Takies ccckaraikudi@preethi.in

No:2871 East 3rd Street, Pudukottai - 622001. PH: 04322-224195, cccpudukkottai@preethi.in 2nd Floor Vanamalidas building

951, Chamber Commerce Building, Alangacherry, Near MohanStore, Aranmanai, Ramanathapuram - 623501. PH: 04567-222344, cccramanad@preethi.in

No. 128 C 1st Floor. Vanitha towers. Kovai road, Karur - 639002. PH: 04324-241989. ccckarur@preethi.in

Balaji Traders, No.34h Eithairaj plaza, Ellaiamman sannathi kovil street, Vijayapuram, Tiruvarur - 01. PH: 04366-222566. cccthiruvarur@preethi.in

D.No.331 Nehru street, Shop No S-2, Krishna complex. Ram nagar. Coimbatore - 641009. PH: 0422-2232687, ccccoimbatore@preethi.in

No:118, West Sambandam Road, R.S. Puram. Coimbatore - 2. PH: 0422-2540687 ccccoimbatore2@preethi.in

Nalliya shopping complex, Basement floor shop #1,Pasupathi Street, Udumalpet - 642126. PH: 04252-221477, cccudumalpet@preethi.in Shop No: 6, 84 Periyar street, Near Nadumariamman Kovil, Erode - 1. PH: 0424-2221200, cccerode@preethi.in

> No. 52 Muthusamy street, Gajalakshmi Theatre backside, Tiruppur - 641604. PH: 0421-4242341, ccctirupur@preethi.in

No.22 Mariammankovil street. Coonoor - 643101. PH: 0423-2236878. ccccoonoor@preethi.in

Karnataka

No,41/14, Raja Ram mohan Roy Extn, 2nd cross near Central Library. Bangalore - 560027. PH: 080-22131819/22130362, cccbangalore@preethi.in

Rajaji Nagar, Bangalore - 560010. PH: 080-23324161, cccjnblr@preethi.in

Maidan 1st Cross Road. Mangalore - 575001. PH: 0824-2410434, cccmangalore@preethi.in

No.12 Neeleegin road, Madiman Complex Hubli - 580029. PH: 0836-2352077 ccchubli@preethi.in

461/c, 1st Floor, Halappa Complex, Durgigudi, Near Jail Circel, Shimoga - 577201. PH: 08182-229759, cccshimuga@preethi.in

#1435, L-4, 7th North Cross, Irwin Road, Lashkar Mohalla, Mysore - 570001. PH: 0821-2443966, cccmysore@preethi.in

Andhrapradesh

1-8-703-715. Shop No.21. Alekhya complex, Shankarmatt, Nallakuntta Opp. Vegetable market. Hvderabad - 500044, PH: 040-27661588. ccchyderabad@preethi.in

No. B-7 1st floor, Huda Complex Saroor Nagar, Hyderabad - 500035. PH: 040-24044858. ccchvdsrm@preethi.in

Commercial Shop No.25 Global Enclave, Aruna Co-op Society. Kukatpally PH: 040-23063848. Hyderabad - 500072. ccckukatpalli@preethi.in

No. 201 Diamond towers, 1-1-37/38 Main Guard. Secunderabad - 500003. PH: 040-27819516, cccsecunderabad@preethi.in

115, Bazaar street, Thirupathi - 575001 PH: 0877-2228966, cccthirupathi@preethi.in

D.No.24-2-7 1st floor, N.R.P road, Gandhi nagar. Viiavawada - 520003. PH: 0866-2431158, cccvijayawada@preethi.in

Shop No.11. Pawan commercial Complex Dabagarden, Main road, Vizag - 530020. PH: 0891-2541915, cccvizag@preethi.in

CUSTOMER CARE CENTRES

D.no.21-13-23, Behind Nagadevi Theatre, Opp.Bommana Hospital, **Rajahmundry - 533103**, PH: 0883-2441321. cccrajamundry@preethi.in

D No,40/17-4, Vaddgeri Park Road, **Kurnool-1**. PH: 08518-222358, ccckurnool@preethi.in

No. 7-2-11, 1st floor, Padmakshamma Lane, Opp Hanuman Temple, New Buustand road, Hanamkonda - 506 001, **Warangal** PH: 0870-2447006, cccwarangal@preethi.in

No.48,3/5 Brodipet back side of hotel, Sindhoori, Beside sub jail, **Guntur** Dt -522002

PH: 0863-2214551, cccquntur@preethi.in

No. 15/591, James Garden, Opp Navatha Transport, Nellore Dt. **Nellore** PH: 0861-2316141. cccnellore@preethi.in

No.22B-1-9/2, T.A.T Pvt ltd., G.N.T Road, **Eluru** west godavari dt-534002. PH: 08812-221841. ccceluru@preethi.in No. 9-11-61662, Khammam Dt- 507001 **Khammam.** PH: 08742-228970 ccckhammam@preethi.in

No. 10-1-14, Gudi vedsi near 7,Road Junction Srikakulam - 532001, PH: 08942-2224488 cccsrikakulam@preethi.in

No. 20/1190, Vamsi Complex, Ramesh theater **Kadapa** - 516001, PH: 08562-246552. ccckadapa@preethi.in

No. 4-63, Beside Rohini Hospital, Janmabhoomi Nagar, **Manchierial-** 504208. PH: 08736-2534222. cccmanchireal@preethi.in

No. 5-401/2, Ravi Angaluylu street, Kurnool Road, **Ongole** - 523001 PH: 08592-282914. cccongole@preethi.in

Kerala

Shop No.188 & 19 1st floor, Telugu chetty samudayam complex, karamna p.o, **Thiruvnanthapuram-695002** PH: 04712341216, ccctrivandrum@preethi.in No. 39/2542, B2 1st Floor, Govind building, M.G road, Ernakulam, **Cochin-16**. PH: 0484-2370781, cccernakulam@preethi.in

14/382, Casamerina complex, Near AKG Hospital, Talap, **Kannur - 670004**. PH: 0497-2765948, ccckannur@preethi.in

5/3472 Merry land Square, Thiruthiyadu road, Near baby memorial hospital, **Calicut - 673509.** PH: 0495-2724080, ccccalicut@preethi.in

No 341, Assissi Building, Alphonsa hospital road, **Chenganacherry - 686101**. PH: 0481-2424383. cccchanga@preethi.in

Building no: KP-VII/712, Opp. Sana auditorium, Munnan kutty, Kilikollur, Kollam - 691 004. PH: 0474-2708800. ccckollam@preethi.in

PMC - V/259, Oushadi junction, Kaladi road, **Perambavoor - 683542** PH: 0484-2595723, cccperumbavoor@oreethi.in Building No. 91/4, Ward No. 6 Vettipuram, **Pathanathitta** dist. Pin code - 689649 PH: 9895996910. cccpathannathitta@preethi.in

A&C 26/1401 Sri Kumar Building, CCSD Road, Alapuzha - 688011, PH: 0477-2230986. cccalapuzha@preethi.in

No. 1410 A-29, 2nd floor Kottachery, **Kanhangad**-671315, PH: 0467-2200799 ccckanhangad@prethi.in

Maharastra

509, Janki center, off veera desai road, Andheri (W), **Mumbai - 400053.** PH: 022-26731650, cccmumbai@preethi.in

Asirwad Co-operative housing Seciety, Shop No, 21,156/3 Mangalwar peth,Barne road, Pune - 411011. PH: 020-32537536, cccoune@preethi.in

OVERSEAS SERVICE CENTRES

QATAR

GOLDEN HOUSE Blue Salon Building, Suhaim Bin Hamad Street, P.O. Box 3750, Doha, Qatar. Tel: 97-44-478 606. Fax: 97-44-791 138.

UAE:

ELEMENT MIDDLE EAST LLC, P.O. Box 6218, Dubai. Tel: 97-1-4-3530 987. Fax: 97-1-4-3534 366. email: elemenet@emirates.net.ae

BAHRAIN:

F.F. WATCH CO. WLL, P.O. Box 164, Manama, Kingdom Of Bahrain. Tel: 97-33-253 729, 215 937. Fax: 97-33-277 708. email: abbas786@batelco.com.bh

KUWAIT

FIVE STAR EST.
Salhiya Fahed Al-Salem Street, Al-Salamah Tower
Mezzanine Floor Shop No. 10, 11, 13, 14,
PO Box : 4734 Safat Code No. - 13048. Kuwait.
Tel : 00965 2437630, 00965 2401482
Fax: 00965 2407630.

email: fivestar2005@yahoo.co.in fivestar@gmail.com

INDONESIA:

PT ANEKA DIMARCO, Komplek Grenvil, Blok AS-38, Kelurahan Duri Kepa, Jakarta 11510. Tel: 62-21-6385 8674, 6385 8223. Fax: 62-21-6313 039. email: dci@dnet.net.id

SRI LANKA:

ESWARAN BROTHERS MARKETINGPVT.LTD. Head Office: 267, Sea Street, Colombo 11. Tel: 94-1-435 842, 432 599. email: ebmarket@sltnet.lk Branches: 536, R.A. De Mel Mawatha, Colombo 03. Tel: 94-1-581 479, 587 240. 104/11, Grandpass Road, Colombo 14. Tel: 94-74-796 727, 796 796.

SINGAPORE:

JOTHI HOLDINGS PTE LTD JOTHI'S BUILDING 1, Campbell Lane, Singapore 209882 Tel: 63387008 H/P: 98167425 Fax: 63380070 E-mail: jothistore@pacific.net.sg Website: www.jothi.com.sg

Preethi®

Range of Home Appliances

- Established in 1978
- × 9 Million Customers
- ★ 70 Customer Care Centres
- ★ 400 Authorised Service Centres
- ★ Over 7000 Dealers

Mixer Grinders

× Exports to U.S.A, Middle East, Far East, and Sri Lanka





Preethi Kitchen Appliances Pvt. Ltd. (Unit - I)

Wet Grinders

Survey No. 112, Natham Ekattur Road, Off IT Highway Thalambur Village, Kancheepuram Dt - 603103. INDIA., Telephone: 91-44-2743 5304. Fax: 91-44-2496 0349.email: info@preethi.in, Website: www.preethi.in

MADE IN INDIA

41000783-B

Customer Care: 044 - 2432 8822