

**SERVICE AND REPAIR:** If the service is required for the product, the purchaser should contact Acetron Trade LLP Customer Service at support@acetron.in or by calling 1800 22 2468.

Disputes if any shall be subject to Mumbai Jurisdiction only.

## TRUE SPORTS

### TRUE WIRELESS STEREO EARBUDS



**SOUNDLOGIC**  
by itek™

**Note:** Other functions including volume increase/decrease, next track, you may need to control through your source device.

#### Voice Assistant Operation:

Voice Assistant is a built-in interactive feature that allows you to Start Conversation with Your Siri or Google Assistant, with short press the MF button of the left Earbud (when using both Earbuds) 3 times quickly.

This feature enables you to ask questions and seek assistance on a number of things from your Voice Assistant, even when you're several feet away from your phone. Below are some of the many examples listed below.

Note: Google Assistant is available on eligible Android 5.0 devices or later. Works on Lollipop, Marshmallow and Nougat Android Phones with Google Play Services, >1.5GB of memory and 720P or higher screen resolution. Please ensure Google Assistant App is downloaded and made as default Voice Assistant on your mobile device.

**While the Earbuds are paired using Bluetooth, short press the MF button of the left Earbud 3 times quickly and release to start conversation with your Siri or Google Assistant. An indication tone would be heard before you speak into the Earbud.**

- Example 1: Short press the MF button of the left Earbud 3 times quickly and release, then speak into the Earbud(s), how's the weather today? Voice Assistant will reply with something like: mainly cloudy with a few showers.
- Example 2: Short press the MF button of the left Earbud 3 times quickly and release, then speak into the Earbud(s), what's the time now? Voice Assistant will reply with something like: it is 8pm now.
- More examples:  
Set an alarm for 7am tomorrow.  
Play some music.  
What's in the news?

#### Troubleshooting:

Symptom	Solution
No Sound	<ul style="list-style-type: none"><li>• Power On the Earbud(s) and charge the battery</li><li>• Increase the volume on your mobile device and music source</li><li>• Move your mobile device closer to the Earbud(s)\ and away from any interference or obstructions</li><li>• User a different music source</li><li>• Connect another mobile device</li></ul>
Poor Sound Quality	<ul style="list-style-type: none"><li>• Use a different music source</li><li>• Connect another mobile device</li><li>• Move your mobile device closer to the Earbud(s) and away from any interference or obstructions</li></ul>
Battery Won't Charge	<ul style="list-style-type: none"><li>• Secure the ends of the USB charging cable</li><li>• Try another charging source</li></ul>
Your Google Assistant not responding	<ul style="list-style-type: none"><li>• This is only available for Android Mobile Devices</li><li>• Make sure Google Assistant is downloaded on your mobile device and set to default voice assistant</li><li>• Make sure your Android Mobile Device is Bluetooth paired with Earbud</li><li>• Make sure you are in a country where Google Assistant is available</li><li>• For additional support, visit <a href="http://www.support.google.com/assistant">www.support.google.com/assistant</a></li></ul>
Loud Dial Tone Noise When Activating Google Assistant	<ul style="list-style-type: none"><li>• Make sure you have latest version of Google Assistant App</li><li>• On your Android mobile device, go to Settings &gt; Apps &gt; Google App &gt; Disable. After that, tap Enable (If you have uninstalled Google App, please uninstall and reinstall the App).</li></ul>

#### Care and Maintenance:

Read the following recommendations before using the Bluetooth Earbuds. Following these you will be able to enjoy the product for many years.

- Don't expose the Bluetooth Earbuds to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the device.
- Don't expose the device to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the device in a fire as it will result in an explosion.
- Don't expose the device to contact with sharp objects as this will cause scratches and damage.

- Don't let the device fall on the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the device as it may get damaged if you are not professional.

#### Specifications:

Bluetooth specification	Bluetooth 5.0
Operating distance	10m
Working time	5 hours
Charging input voltage	DC 5V
Charging time	About 2 hours
SpeakerPower (each Earbud)	3mW
Built-In Battery	Charging Case: 400mAh Bluetooth Earbud: 50mAh (each)
Size	Charging Case: 80mm (L) x 50mm (D) x 33mm (H) Bluetooth Earbud: 31.5mm (L) x 28mm (D) x 43.5mm (H) (each)
Weight	Charging Case: 45g Bluetooth Earbud: 7g (each)

(Note: Battery life & charging time may vary based on usage & types of devices used.)

#### Limited Warranty:

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

**WARRANTY DURATION:** All the materials and workmanship are warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

**WARRANTY COVERAGE:** This product is warranted against defective materials or workmanship. This warranty is void if the product has

been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of the defects in material or workmanship. This warranty is effective only if the product is purchased and operated in INDIA, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**WARRANTY DISCLAIMERS:** This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with sale of our products.

**WARRANTY PERFORMANCE:** During the above one (1) year warranty period, a product with defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the warranty period or thirty (30) days which ever is longer.

**WARRANTY LIMIT:** The maximum liability of the company shall not exceed the actual purchase price paid by the purchaser.

**SOUNDLOGIC**  
by itek™

## TRUE SPORTS

### TRUE WIRELESS STEREO EARBUDS



**RAW**  
SERIES

**Instruction Manual**  
Please read all instructions carefully and retain for future use.

**Getting Started:**

- Remove the product from the box.
- Please retain all packaging after you have checked and counted all the parts and the contents against the Package Contents list.

**Package Contents:**

- SL TrueSport True Wireless Stereo Earbuds
- Charging Case
- Type-C USB Charging Cable
- Extra Earbuds (Small,Medium,Large)
- Instruction Manual

**Features:**

- HD Sound - Premium quality membrane drivers that produce high quality sound with heavy bass.
- Long Battery Life - 5 hours playback time on a single charge and a total of 20 hours with the charging case.
- Built-in microphone for hands-free-calls
- Built-in controls for call, music and voice assistant.
- Auto Turn On/Off - Auto Turn On/Off features allows connecting and disconnecting the earbuds when placed or removed from the case.

**Safety Instructions:**

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not use the unit with wet hands.

Do not put objects into any of the openings.


Keep the unit free from dust, lint etc.

Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children.

This product is not a toy.

Do not use the headset at excessive volume levels, as damage to hearing may occur.



1	MF (Multi-Function) / Phone Button
2	Built-in Microphone
3	LED Indicator
4	Charging Slots
5	Charging Port
6	Charging Case LED Indicator
7	Charging Connectors

**INSTRUCTIONS FOR USE:**

**Charging Instructions:**

The Charging Case and Bluetooth Earbuds come with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Please recharge the battery by following either methods every time they drain out.

**To charge the Charging Case (without Bluetooth Earbuds):**

Plug the Type C end of the included USB charging cable into the charging port of the Charging Case. Plug the other end into a suitable USB port such as the one on your computer or other devices made for USB charging. Blue LED light will flash indicating that it is being charged.

It takes about 2 hours for the case to charge fully. When the battery is fully charged, all 4 LED lights will stay on.

**To charge the Bluetooth Earbuds:**

1. After fully recharging the Charging Case, disconnect it from charging.
2. Put the Bluetooth Earbuds into respective charging slots correctly.
3. The LED light indicator on the Earbuds turns red to indicate that the battery is being charged. It takes less than 2 hours for the Earbuds to fully charge. When the battery is fully charged, the red LED light will turn off, and the blue LED light on the Charging Case will also turn off.

**Turning on/off the Bluetooth Earbuds:**

Take out the Earbud from the Charging Case, it will turn on automatically [Or, if the Earbud is not stored inside the Charging Case, press and hold the MF button for 2 seconds to turn ON.]

Press and hold the MF button of the Earbud for 4 seconds to turn OFF the device. [Or, put the Earbud back into the Charging Case, it will turn off for recharging automatically.]

**Pairing both Bluetooth Earbuds with Bluetooth devices (phone or tablet that support call-answering):**

- Take out both Earbuds from the Charging Case, it will turn on automatically and the LED flashes red and blue [\*Or, if both Earbuds are not stored inside the Charging Case, press and hold the MF button for 2 seconds to turn ON. An indication tone will be heard and the LED flashes red and blue.]
- After few seconds, you would hear another indication tone when both Earbuds connected together. The LED light indicator on the right Earbud will flash red and blue, and the LED light indicator on the left Earbud will flash blue slowly.
- At this point, activate the Bluetooth function on your mobile device, and search for Bluetooth devices near you.
- Once you have activated Bluetooth on your mobile device, select the "SL TrueSports" from the list of available Bluetooth devices.
- Once paired successfully, an indication tone will be heard and the LED on both units will flash blue slowly.

**Making a call with the Bluetooth Earbuds in Stereo pairing mode**

**Basic operation:**

Function	Operation	Button
Answer incoming call	Incoming Call	Short press the Phone button of one Earbud to answer an incoming call.
Reject incoming call	Incoming Call	Press and hold the Phone button of one Earbud for 2 seconds and release
End call	Incoming Call	After your phone conversation, short press the Phone button of one Earbud
Redial last number	Standby mode and connected to a device	Short press the Phone button of the right Earbud 3 times quickly

**Note:** both Earbuds support phone conversation.

**Listening to Music Wirelessly in Stereo pairing mode:**

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Earbuds to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Pause	Playing music	Short press the MF button of one Earbud will pause the music
Play	Pausing	Short press the MF button of one Earbud will resume the music
Previous Track	Playing music	Short press the MF button of the left Earbud twice
Next Track	Playing music	Short press the MF button of the right Earbud twice

**Note:** Other functions including volume increase/decrease, you may need to control through your source device.

**Pairing either one Bluetooth Earbud with Bluetooth devices (phone or tablet that support call-answering):**

- Take out one Earbud from the Charging Case, it will turn on automatically and the LED flashes red and blue [Or, if the Earbud is not stored inside the Charging Case, press and hold the MF

button for 2 seconds to turn ON. An indication tone will be heard and the LED flashes red and blue.)

- Place the Bluetooth Earbud and Bluetooth device (phone or tablet that support call answering) no further than 1m apart from each other;
- Activate the Bluetooth function on your mobile device. Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your mobile device, select the "SL TrueSports" from the list of available Bluetooth devices.
- If required, enter the password '0000' to confirm & finalize pairing.
- Once paired successfully, another indication tone will be heard and the LED will flash blue slowly.
- You can now start to use the Earbud.
- If pairing is unsuccessful, turn off the device first and then re-pair following the above steps.
- Once you have paired the Bluetooth Earbud with a mobile device, the Earbud will remember this mobile device and will pair automatically when its Bluetooth is activated within the range, during subsequently pairing. You do not need to re-pair any previously connected devices.
- The Bluetooth Earbud will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.

**Making a call with the Bluetooth Earbud in Bluetooth mode**

**Basic operation:**

Function	Operation	Button
Answer incoming call	Incoming Call	Short press the MF button to answer an incoming call.
Reject Incoming Call	Incoming Call	Short press the MF button for 2 second and release
End call	Incoming Call	After your phone conversation, Short press the MF button
Redial last number	Standby mode and connected to a device	Short press the MF button 3 times quickly

**Listening to Music Wirelessly:**

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Earbud to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Pause	Playing music	Short press the MF button will pause the music
Play	Pausing	Short press the MF button will resume the music
Previous Track	Playing music	Short press the MF button twice