# WARRANTY OVERVIEW

Carvaan comes with a 1 year Warranty on all parts, excluding accessories. This includes servicing/ repair or replacement of damaged parts.

The warranty does not apply and does not cover the following:

• Liability for loss of data/content loaded in the product due to misuse or tampering.

• Damage caused due to force majeure events; events caused by fire, water, electrical disturbances etc.; events beyond the control of Saregama; acts of negligence or mishandling; usage for commercial, business, industrial, educational or rental purposes

### **WARRANTY CARD**

Customer's Name: Customer's Address:		
Product Serial No.:		
Date of Purchase:		
Expiry Date:		
I accept the terms ar warranty.	nd conditions of the	
Retailer's Name:		
Retailer's Signature/	Seal:	
	Customer's Signature	

### **IMPORTANT LINKS**

Station List & Song List: www.saregama.com/carvaan/wifi/songlist

Detailed Warranty:

www.saregama.com/carvaan/wifi/warranty

Download the "Saregama Carvaan" app from the **Apple**/ **Android** store.



# WARRANTY TYPE

Home service and carry in warranty are provided.

Home service warranty requires customers to have a technician visit their home and service the product. This type of warranty can be availed by customers living in locations where there is an authorized service center.

Carry-in Warranty service requires that the Product be brought by the Customer, at his/her sole cost and responsibility, to the Authorized Dealers along with the original invoice.

Once the Product is serviced/ repaired/ replaced, the Customer shall be responsible to pick-up the Product from the concerned Authorized Dealer.

# CARVAAN UNIT AND Wi-Fi CONNECTIVITY

To enjoy Wi-Fi based stations the Carvaan unit needs to be connected to Wi-Fi. (ensure the Wi-Fi speed is good to enjoy an uninterrupted experience)

#### SET UP PROCESS:

#### On Carvaan

• On your Carvaan unit, press the 'Saregama' button, followed by 'Wi-Fi' category button

#### On your mobile phone

• Turn on the Bluetooth of your mobile phone / handset

- Download the 'Saregama Carvaan' app
- Open the app
- Choose 'Play on Carvaan'
- Next, select Carvaan 2.0 from the list of available devices
- Tap on the menu on the top left of your screen & select "Connect to Wi-Fi"
- Choose a Wi-Fi network & enter the
  password; the app will remember your Wi-Fi password

To change the network, go to "Connect to Wi-Fi" page on the app & select the preferred network.

Note: Wi-Fi charges will be as per your Wi-Fi service provider





USER MANUAL HINDI | हिंदी

## **BUTTONS & PORTS ON SAREGAMA CARVAAN**





volume



0.0

3.5 mm audio

jack for connecting

externa

speakers/

headphones

Full battery charge time: 6-7 hours; Battery usage: Approximately 5 hours once the battery is fully charged

The battery charging indicator will display:

a. Red light when Carvaan is being charged

b. Green light when Carvaan is fully charged

To choose a mode, press the corresponding mode button on the unit/ remote

1. **SAREGAMA:** 5000 pre-loaded evergreen songs categorized into Artistes, Specials, Geetmala & Wi-Fi. This mode is the default mode on first power on/reset

2. **USB**<sup>\*</sup>/**AUX IN:** Plug in a USB into the USB port on Carvaan to enjoy your personal collection of songs. You can also connect an Aux cable in the Aux IN port on the back panel of Carvaan to play songs from your phone/tablet. Press the mode button to switch between USB and Aux In

3. **FM/AM**<sup>\*\*</sup>: Listen to local FM/AM stations. Press the mode button to switch between FM and AM

FM frequency: 87.5 to 108 MHZ AM frequency: 520 to 1620 KHZ

Note: We recommend that you do not put the unit on charge while listening to FM/AM as it will interrupt the signal

4. **BLUETOOTH**<sup>\*\*\*</sup>: Pair your mobile phone / tablet with Carvaan. Enjoy songs stored on your personal device on Carvaan speakers

\*support for USB 2.0

\*\*AM station will play as per broadcast timings \*\*\*support for BT version 4.1

#### categories





## SAREGAMA CARVAAN APP

Download the 'Saregama Carvaan' app from the Apple / Android store to enjoy a host of free and subscription based services.

Free services – Use the app to find a song. create playlists to playout on your Carvaan unit.

Note: To use the app, press the 'Saregama mode' button on Carvaan. Connect the app & Carvaan using Bluetooth on your phone/tablet.

Subscription services - Subscribe to the app and listen to the songs on your phone/tablet without being connected to the Carvaan unit

Refer to the enclosed insert for steps on how to connect the app and Carvaan unit.

Available on the App Store		<sup>Get it on</sup> Google <sup>-</sup> play	
----------------------------	--	--	--

Choose a category in Saregama Mode

I⊷∏

1. Artistes: 65+ music stations dedicated to legends like Lata Mangeshkar, Kishore Kumar, Asha Bhosle, Mohd. Rafi, R.D. Burman, Gulzar, Rishi Kapoor, Amitabh Bachchan, Noor Jehan, Mukesh, Nargis, Rekha etc.

2. Specials: 15+ music stations dedicated to Specials like Romance, Ghazal, Gurbani, Bhakti, Kapoors, Sad, Songs with Dialogues, Hindustani Instrumental, Favourites etc.

3. Geetmala: 50 years of Ameen Sayani's Geetmala spanning across 50 music stations

4. Wi-Fi: Many Wi-Fi based stations across genres like devotional, health & wellness, kids, entertainment, and much more, To enjoy Wi-Fi based stations connect Carvaan Gold to a Wi-Fi network using the 'Saregama Carvaan' app.

Go to page 4 for details on how to connect the Carvaan Gold unit to Wi-Fi.

> Voltage: 110-240V Frequency: 50/60 Hz for input and 5V 1A for output

#### External Antenna

Insert the antenna into the AUX IN port for improved reception of local FM stations

battery





# SAFETY HANDLING

#### 1. CARE FOR PRODUCT

a. Keep Carvaan away from dust and excessive heat (heat registers, stoves etc.)

b. Prevent spillage of water or any other liquid as this can cause failure of Carvaan or could prove to be a potential fire hazard

c. Clean the unit with a dry cloth only

d. Do not walk on or pinch the power cord close to the plug

e. Do not immerse Carvaan or the remote into water

f. Remove the remote battery when it is not used for longer duration

q. Do not mix different brands or types of batteries in the remote

#### 2. CARE FOR BATTERY

a. Do not expose the battery to heat sources greater than 60°C

b. Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods

To replace the remote control battery:

- 1. Open the battery compartment
- 2. Insert a fresh CR2025 battery with the correct polarity (-/+)
- 3. Close the battery compartment
- 4. Discard the used battery

c. Do not subject the battery pack to a mechanical shock

d. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eves. If contact has been made, wash the affected area with water and seek medical advice

e. For prolonging battery life, avoid discharging the battery completely

#### 3. OTHERS

a. Use attachments/accessories as specified by the manufacturer

b. Please contact an authorized service center for any repair/ servicing requirements or call the toll free no. 1800-102-7799 for any auerries

Waste electrical products should X not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

### Choose your preferred category in Saregama mode