



PURA E Notebook PC

e-manual

NS14A6

(14")

The Notebook PC now in your hands has successfully completed the "AVITA CHECK".
For more information on the products and services, please visit
www.avita.com/support

Safety Precautions

WARNING

Do not attempt to disassemble the cabinet. This device does not contain customer serviceable components. Refer servicing to qualified personnel.

CAUTIONS

- The apparatus and AC adapter shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not use the Notebook PC in the environment at too high or too low temperature, never expose the Notebook PC under strong sunshine or too wet environment. The suitable temperature for the Notebook PC and accessories is 0°C ~ 35°C.
- Always leave sufficient space around the device for ventilation. Do not use or place the device on soft surface such as a bed or cushion which could make the device build up heat.
- When charging, please place the Notebook PC in an environment that has a normal room temperature and good ventilation. It is recommended to charge the Notebook PC in an environment with a temperature that ranges from 5°C ~ 25°C. Please ensure to use only the adapter offered by the manufacturer. Using unauthorized adapter may cause danger and violate the authorization of the Notebook PC and the guarantee article. The maximum operating ambient temperature of the equipment declared by the manufacturer is 35°C.

IMPORTANT

- The AC adapter shall be installed near the equipment and shall be easily accessible.
- Unplug from the wall outlet during a storm.
- No naked flame sources such as lighted candles should be placed on the device.
- Do not pinch, bend, or put heavy or sharp objects on its electrical cord.
- Do not use the device while driving a car or doing any other activities in which loss of concentration could lead to potential harm to self or others.
- Excessive sound pressure from earphones and headphones can cause hearing loss.

Battery safety


This device contains a built-in battery, improper use of which may result in explosion. Do not heat, open, puncture, mutilate, or dispose of the product in fire. Do not leave the device in direct sunlight for an extended period of time, which could cause melting or battery damage. The battery in this device is not user replaceable and should only be replaced by AVITA or a AVITA Authorized Service Provider.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

CAUTION

Excessive use of the device can cause your vision loss.

1. Do rest your eyes for 10 minutes if use the device for 30 minutes.
2. Do not watch the display for children under 2 years of age. Do not watch the display over 1 hour everyday for children above 2 years of age.



R3B886

ROHS


Contents

Safety Precautions	1
Getting Started	5
Getting to know PURA E	5
Charging PURA E	10
Turning PURA E on	12
Put PURA E to Sleep	14
Power Management	15
Basics	16
Start menu	16
Action center	19
Task view	22
Using the touchpad	23
Using the keyboard	26
Connections and Setup	29
External display	29
Connecting to a Wi-Fi network	32
Airplane mode	34
Bluetooth	35
Brightness	36
Volume	37
Troubleshooting	38
Specifications	40
Legal and Safety Notices	41

Getting Started


Getting to know PURA E

Top view



- 1 Microphone**
For voice input.
- 2 Camera indicator**
The camera indicator lights up when the built-in camera is in use.
- 3 Camera**
The built-in camera allows you to take still photos and record videos.
- 4 Power button**
Press it to turn the Notebook PC on or off.
- 5 Power indicator**
The power indicator lights up when the Notebook PC is powered on and blinks slowly when the Notebook PC is in Standby mode.
- 6 Touchpad**
Move the cursor and selects options.
Functions as a mouse.

Left side



1 Charging indicator

Show the battery's charge status.

- **Orange:** Charging
- **Green:** Fully charged
- **Orange (blinking):** Low battery

2 DC jack

Connect with 12V DC charger.

3 USB 3.0 (5V DC, 0.8A) port

Connect to a USB storage device or a mouse, keyboard, or camera.


4 Mini-HDMI OUT port

Connect to a TV or a display device.

5 USB Type-C port (5V DC, 1.0A)

(for data only)

Right side



1 Headphones jack

Headphones connection for personal listening.

2 USB 2.0 (5V DC, 0.8A) port


Connect to a USB storage device or a mouse, keyboard, or camera.




Charging PURA E



IMPORTANT! Please Read.

We recommend fully charging your Notebook PC before using it for the first time. For optimum performance, please connect the provided AC adapter to your Notebook PC when it falls below 20% charge.



Charging indicator	Status
	Orange: Charging
	Green: Fully charged
	Orange (blinking): Low battery

NOTE

- Use ONLY the included AC Adapter to charge the battery.
- The AC Adapter may vary in appearance, depending on models and your region.
- Charging time will vary depending on remaining battery level. Charging from 0% to 70% will take approximately 1.5 hours. You may not be able to turn on your Notebook PC within a few minutes if the battery was fully drained.

In order to keep the battery working in best condition, please pay attention to the following:


- The included AC adapter is for use with this unit only. Do not use it with other equipment.
- Please do not charge the battery in high temperatures.
- Do not wait for the battery to be fully depleted before charging again. Keep the battery charged as needed.
- If your Notebook PC has not been used for a long period of time, the battery might be in over discharge protection mode and may take longer to charge.

Turning PURA E on

Starting for the first time

When using the Notebook PC for the first time, you will be required to setup the following:

1. Press the **Power** button to turn on your Notebook PC.







2. Select the language, then click **Yes**.
3. Follow the onscreen instructions to configure your Notebook PC.

About Windows Activation

Windows will be active automatically once you connect your Notebook PC to a WiFi network.

Turning PURA E off

1. Click the  icon in the lower-left corner of the screen or press the  **Start** key on the keyboard to get to the **Start** menu.
2. Click the  **Power** icon in the lower-left corner of the screen, it will display 3 options (Sleep, Shut down and Restart).
3. Select **Shut down** to power the Notebook PC off.




NOTE

- Save all data before turning your Notebook PC off.
- If your Notebook PC is unresponsive, press and hold the **Power** button for several seconds and follow the on-screen instructions to force SHUT DOWN the unit.

Putting PURA E to Sleep


You can put your Notebook PC to Sleep mode by doing either of the following:

- Go to the **Start** menu and click the  **Power** icon in the lower-left corner of the screen, select and click **Sleep**.
- Briefly press the **Power** button to put the Notebook PC in sleep mode. If you don't operate for some time, the Notebook PC will enter sleep mode automatically.

Power Management



When the apparatus is not connected to the power adapter and not providing the main function or when other energy-using products are not dependent on its function, the default system settings and its characteristics enable the apparatus to activate display sleep mode within 5 minutes of user inactivity, and to activate a distinct sleep mode within 10 minutes of user inactivity. In the same scenario, when the apparatus is connected to power adapter, will activate display sleep mode within 15 minutes of user inactivity, and activate a distinct sleep mode within 25 minutes of user inactivity. When in sleep mode, the system becomes fully usable within 5 seconds via network connections or user interface devices. The power management function is automatically switched on by the default system settings.

Go to **Settings -> System -> Power & sleep** to manage how your Notebool PC use power.




Basics

Start menu

Click the  icon in the lower-left corner of the screen to get to the Start menu. You can also open the Start menu by pressing the  **Start** key on the keyboard.


Live titles



Taskbar

Live Tiles on the screen change and update in real time so you can get real-time updates about news or sports, check what your friends are up to, and get the latest weather forecast.

Expand

Click this icon  in the upper-left corner of the screen to expand the **START** menu.

Account options

Click on your account name to change account settings, lock your device or sign out of your account.

Settings

Allows you to access the settings of your Notebook PC. Click it to enter the **Settings** screen.

Power











Click  icon to Sleep, Shut down or Restart your Notebook PC.

Start

Click the  **Start** icon to open/close the Windows Start menu.

Taskbar


The below table lists some of the frequently used icons in the Taskbar:


Icon	Description
	Shows the battery status.
	Displays when a Wi-Fi network connected.
	Displays when there is NO a Wi-Fi network connection or Wi-Fi is turned off.
	Airplane mode is on.
	Adjusts the speaker volume.
	Launches Action Center
	Launches Search.
	Shows the recent task.
	Shows all opened tasks in a single view.
	Launches the File Explorer.

Action Center

It allows you to receive system notifications, such as updates. It also has a really useful Quick Actions on the bottom.

Checking notifications

1. Click the  icon in the lower-right corner of the screen to launch the ACTION CENTER screen.
2. All messages appears in the Action Center and you can select and click them to read.



Tip: You can go to **Settings -> System -> Notifications & actions** to set the Notifications and Actions.



NOTE


- Select **Expand** or **Collapse** to expand or minimize the **Quick Actions** menu.

Quick Actions menu

Tablet mode	Opens or closes the Tablet mode.
Network	Enables or disables Network, and connects to a wireless network so that you can check email, search the Web, access social media websites.
All settings	Allows you to access the settings of your Notebook PC.
Nearby sharing	Turns on/off Nearby sharing.
Airplane mode	Enables or disables Airplane mode. Turns it on to stop all wireless communication.
Location	Enables or disables Location. If this setting is on, each person who signs in to this device can change their own location settings.
Focus assist	Choose which notification you'd like to see and hear so you stay focused (off, Priority only or Alarms only).
Mobile hotspot	Activates the Mobile hotspot.
Night light	Enables or disables Night light.
Bluetooth	Enables or disables Bluetooth.
VPN	Add a VPN connection.
Battery saver	Turns on/off Battery saver.
Screen snip	Opens the Screen snip options.


Project	Opens the Project options.
Connect	Searches for wireless display and audio devices.

Task view

If you have a lot of apps and programs opened, click the  icon on the taskbar to see all of your running apps and programs. You can select and click any item to open it.

Creating a new desktop

Select and click **+ New desktop**, a new desktop will be added. Then you can open your desired apps and programs on the new desktop.



Deleting a desktop


Move the cursor over the desktop you want to delete, then select  in the upper-right corner of the desktop.

Using the Touchpad

Use the Touchpad to move the cursor or select an item. The left and right buttons of the Touchpad act the same as the left and right buttons of a mouse.

Moving


Slide your finger on the Touchpad to move the cursor.




Left-click

Tap the touchpad or press the left touchpad button.

- In the Start menu, click an app to launch it.
- On the File Explorer desktop, double click an application to launch it.




or



Right-click


To right-click an item, press the right touchpad button.

- In the Start menu, select an app and press the right touchpad button to launch the Setting bar.
- On the File Explorer desktop, select one folder or file and press the right touchpad button to open the right-click menu.




Dragging and dropping

Press and hold the left button. Select an item using your other finger then drag and drop it to a new position.




Two-finger scroll (up/down)

Slide two fingers to scroll up or down.




Two-finger scroll (left/right)

Slide two fingers to scroll left or right.




Zoom out

Pinch two fingers while viewing a website, map, or image.



Zoom in

Spread two fingers apart while viewing a website, map, or image.





















NOTE







- Please keep your fingers dry and clean when using the Touchpad.

Using the Keyboard

Function keys












Press and hold the **Fn** key, then press a hot key to trigger the following commands:





















- | | | | |
|---|---|---|--|
|  | + |  | Decreases the screen brightness. |
|  | + |  | Increases the screen brightness. |
|  | + |  | Launches the Search Windows. |
|  | + |  | Launches the Settings screen. |
|  | + |  | Turns the speakers on and off. |
|  | + |  | Decreases the sound volume. |
|  | + |  | Increases the sound volume. |
|  | + |  | Returns to the previous media file. |
|  | + |  | Plays or pauses a selected media file. |

-  +  Skips to the next media file.
-  +  Switches between the display screen and an external monitor (if connected).
-  +  Enables or disables the Touchpad.

Windows keys

You can also use the following shortcuts to help you to launch the applications and navigate the Windows 10.

-  Opens or closes the Start menu.
-  +  Launches **Action Center**
-  +  Launches the desktop
-  +  Launches **File Explorer**
-  +  Launches **Feedback Hub**
-  +  Launches Windows **Settings**

	+		Launches the CONNECT screen
	+		Activates the Lock screen
	+		Minimizes all currently active windows
	+		Launches the PROJECT screen
	+		Opens the Run window
	+		Launches Search window
	+		Chooses the programs on the taskbar
	+		Opens Ease of Access setting menu
	+		Opens the context menu of the Start button
	+		Prints the current screen.


Connections and Setup

External display

You can connect the Notebook PC to an external display device. The cables required to connect an external display are sold separately.


Connecting to a display

1. Connect the Notebook PC to a TV or other display device using an HDMI cable (not included) through the mini-HDMI port.



2. Turn on your TV or other display device and select its input mode.



3. Go to **Action Center** menu, select and click **Project**.





Tip: You can also use the following shortcuts to launch the **Project**.



4. Select your desired mode as follows:

	PC screen only Shows the screen on the Notebook PC only.
	Duplicate Shows the screen on both the Notebook PC and the external display.

	<p>Extend Extends the screen to the external display.</p>
	<p>Second screen only Shows the screen on the external display only.</p>


Tip: You can also select the dual view (extend) mode. Go to **Settings -> System -> Display**, and select **Detect** on the **Multiple displays** option.

Connecting to a Wi-Fi network


Connect the Notebook PC to a wireless network to use the Internet.

1. On the Taskbar, select and click  .

Access Point
(AP) list



2. Select a network from the list of detected wireless networks and select **Connect automatically** -> **Connect**



3. Enter the **Access Point's** password, if necessary, and select **Next**.

Tip: You can also go to **Settings -> Network & Internet -> Wi-Fi**, click it to **On**.



NOTE


- If the device finds a network that you connected to previously, it will connect to it automatically.
- If the Wi-Fi network does not appear in the list, it maybe a hidden network, please click "**Hidden Network**" and input SSID name of network along with password for a connection.

Airplane mode

The Airplane mode disables the wireless connection, allowing you to use your Notebook PC safely while in-flight.

If you see ✈ icon displayed in the lower-right corner of the screen, the Airplane mode is on. You should turn off the Airplane mode to enable the wireless network.

1. On the Taskbar, select and click .




2. Select and click ✈ **Airplane mode**.

Tip: You can also go to **Settings -> Network & Internet -> Airplane mode**, click it to **On**.

Bluetooth

You can use Bluetooth to communicate between the Notebook PC and other Bluetooth devices, such as a smartphone.

1. Go to **Action Center** menu, select and click **Bluetooth** to turn it on.



2. Then the Notebook PC will be a discoverable bluetooth device and you can scan it on your other bluetooth device.

Tip: You can also go to **Settings -> Devices -> Bluetooth**, click it to **On**.

Brightness

You can adjust the brightness level of the screen according to your requirements.

Using the keyboard to adjust brightness


Press and hold the **Fn** key, then press the **F2** key to decrease the brightness of the computer screen.




Press and hold the **Fn** key, then press the **F3** key to increase the brightness of the computer screen.



Using the taskbar to adjust brightness

Click the  icon in the lower-right corner of the screen to launch the ACTION CENTER menu. Drag the bar to adjust the brightness.



Brightness adjustment bar

Volume

You can adjust the system volume or sound volume when playing music or video.

Using the keyboard to control volume


Press and hold the Fn key, then press the F7 key to decrease the sound volume.




Press and hold the Fn key, then press the F8 key to increase the sound volume.



Using the taskbar to control volume

Select and click  on the Taskbar, then drag the adjustment bar to your desired volume.

Volume adjustment bar



Troubleshooting

When a problem occurs with the Notebook PC, it is easy to restore the Notebook PC to the factory default settings. Back up important data regularly before a problem occurs with the Notebook PC.

You can go to **Settings** -> **Update & security** -> **Recovery** to recover your Notebook PC.

Reset this PC

If your PC isn't running well, resetting it might help. This lets you choose to keep your personal files or remove them, and then reinstalls Windows. Click **Get started** and then choose an option.

Keep my files

Removes apps and settings, but keeps your personal files.

Remove everything

Removes all of your personal files, apps, and settings.

Advanced startup

Start up from a device or disc (such as a USB drive), change your PC's firmware settings, change Windows startup settings, or restore Windows from the system image. This will restart your PC.

If you want to perform this action, click **Restart Now**.



NOTE

Third-party applications will be removed.

Q & A

The device won't start

- This may happen if your battery is empty. Please connect the provided AC adapter to a wall outlet.

Windows is not active automatically

Windows will be active automatically once you connect your Notebook PC to a Wi-Fi network.

- Make sure that you have a Wi-Fi network connection.

Notebook PC displays network or service error message

- When you are located in places with poor signal, your Notebook PC may lose its Wi-Fi connection. Try moving closer to the Wi-Fi router.

Notebook PC is frozen or a serious error appears

- If the Notebook PC is frozen or suspended, you may need to close the application or refresh your Notebook PC.
- If the Notebook PC is frozen or slow to respond, press and hold the power button for several seconds and follow the on-screen instructions to force SHUT DOWN the unit, then press the power button to turn on your Notebook PC again.

Specifications

Processor

AMD A6-9220e

CPU Speed

1.6 GHz

RAM

4GB DDR4 / 8GB DDR4

Display

1366 x 768

Camera

VGA

USB port

USB Type-C x 1 (for data only)

USB 3.0 Type-A x 1

USB 2.0 Type-A x 1

WiFi Connection

IEEE 802.11 b/g/n

Bluetooth

Bluetooth 4.2

Power

DC 12V (operates with supplied AC adapter)

Specifications and external appearance are subject to change without notice.

Legal and Safety Notices

Copyright and Trademark Notices

Windows and windows logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance. The Wi-Fi Protected Setup Mark is a mark of the Wi-Fi Alliance.

The *Bluetooth*® word mark and logos are registered trademarks owned by the *Bluetooth* SIG Inc. Other trademarks and trade names are those of their respective owners.



HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks, registered trademarks, or service marks of HDMI Licensing, LLC in the United States and/or other countries.

About HDMI

High-Definition Multimedia Interface (HDMI) is a high-speed digital interface that can transmit uncompressed high definition video and digital multichannel audio. It delivers high quality picture and sound quality. HDMI is fully backward compatible with DVI. As required by the HDMI standard, connecting to HDMI or DVI products without HDCP (High bandwidth Digital Content Protection) will result in no Video or Audio output.

All other trademark appearing herein are the property of their respective owners.

Environmental Considerations

The crossed-out garbage can symbol on your product signifies that it falls into the category of electric/electronic equipment. Products of this type contain substances that are potentially dangerous to the environment and to human health. Therefore, you should not dispose of the AVITA electronic device in a regular trash. As such, the current European directives ask that this device be collected:

- At places of distribution in the case of a purchase of a similar electronic product.
- At locally created disposal areas (waste disposal centers, sorted trash system, etc.)

