Pre-instruction Literature

On Receipt

It is our policy to promote safe delivery of all orders. This product shipment has been thoroughly checked, packed and quality certified before leaving our factory.

Visible Loss or Damage

If any of the goods called for on the bill of lading or express receipt are damaged or the quantity is short, do not accept them until the freight or express delivery agent makes an appropriate notation on your freight bill or receipt.

Concealed Loss or Damage

When a shipment has been delivered to you in apparent good condition, but upon opening the packaging if any loss or damage has taken place while in transit, inform the carrier's agent / A. O. Smith representative immediately.

About this manual

This manual is a guide to good practice for operating and periodic maintenance of the A.O. Smith X2 Water Purifier.

This does not contain the full servicing procedures necessary for continued successful operation of this product. The services of A. O. Smith Company Authorised Service Technician must be employed periodically on the same.


Do not operate before reading manual supplied with this product.

Please follow instructions in this manual to ensure personal safety and proper performed by any unauthorised personnel. Always install, operate, inspect and maintain this product in accordance with all applicable standards. Please store this user manual carefully for any future reference.

General Instructions

Safety

Your safety and the safety of your loved ones is paramount. There are several safety related messages in this manual, which have been provided during various steps such as the installation, operation and maintenance of your X2 Water Purifier. These risks. Please always read and follow all safety messages as provided in this user manual.



Do not use this Water Purifier if any part has been under water. Immediately contact a Authorised Service Technician to inspect the Water Purifier and contact A. O. Smith Service personnel to replace any part of the control system which has been under water. Failure to follow this instruction can result in property damage, serious injury or death.

IMPORTANT

These instructions have been written as a guide for the proper installation and operation of your Water Purifier. A. O. Smith will not accept any liability where these instructions have not been followed. However, for your safety and to avoid damage caused by improper installation, it is recommended that Water Purifier must be installed by a Authorised Service Technician.

Before proceeding with the installation instructions:

. Inspect the Water Purifier and its component parts for possible damage. Do Not install or attempt to repair any damaged component parts. If you detect any damage in the Water Purifier, please contact the dealer where the Water Purifier was purchased or call A. O. Smith Customer Care Centre. Verify that the voltage being supplied corresponds to that which is marked on the

Water Purifier manual



OVER A CENTURY OF INNOVATION

A. O. Smith enjoys a rich history of achievements. A glimpse at our 144-years history reveals numerous engineering and technical achievements.

CHANGING THE LOOK AND THE OUTLOOK OF THE WATER HEATER INDUSTRY

A. O. Smith has established itself as a company that can make a difference. It has brought international quality standards to India's water heater industry. The company came to India in 2008, with a revolutionary range of water heaters. It has raised customer expectations, and shown the industry how to meet them. The company now enters the water purifier industry, an industry poised and ready for change. You can look forward to a lot of excitement ahead.







ISO

9001:2015

CERTIFIED



microbial cells and cysts.

qmal VU – 4 spat2

Stage 3 – Carbon block

5tage 1 – Sediment filter

Introduction

Stage 2 – Fine Sediment filter

reiter (ont extru) 40 – č spetč

Manufactured **by A. O. Smith India Water Products Private Limited** Plot 300, Phase - II, KIADB Industrial Area, Harohalli, Kanakapura Taluk, Ramanagara District, Karnataka – 562 112, India. Customer Care No. 1800-103-2468/1860-500-2468 • Website: www.aosmithindia.com CIN: U31909KA2006PTC040282

In the final stage water is passed through Ultra fine filter where it removes deactivated

In this stage water is passed through UV housing wherein UV rays disinfects the water by eliminating water-borne disease causing microorganisms like bacteria and virus making it healthy for drinking.

The Carbon block with high adsorbtion capacity reduces harmful chemicals including

The Fine Sediment filter is used to remove finer physical contaminants present in the water. This improves life of the Carbon block.

The Sediment filter is used to remove physical contaminants such as dirt, dust, soil particles, turbidity present in the water. This improves the life of the Fine Sediment filter

is passed through the various stages and progressively filtered to get purified water which is stored in the inbuilt storage tank.

A. O. Smith X2 water purifier has 5 stages of purification system, wherein the water

UV is a proven disinfection technology used in water purification which delivers micro-biologically safe water. The germicidal langi naide the UV emits ultraviolet energy that has the capacity to alter the nucleic acid (DNA) of viruses, bacteria and cysts of they cannot reproduce and are thereby considered inactivated. The A.O. Smith X.S water purifier incorporating UV purification technology produces germ-free potable water for drinking. Purified water is collected for drinking in a storage tank.

How does the A. O. Smith X2 water purifier work?

pesticides, volatile organic compounds, residual chlorine etc., from water. It also

adsorbs bad taste and odour causing organic compounds from water.


*Under standard test condition. For details visit www.aosmithindia.com Actual product may vary from the image show Part No. : 335300-003_A Date: 13-08-2018

ndicator is blinking, check feed water supply to the purifier. This indicates, that the system is switch OU/OFF condition. When the Power ON Power ON indicator № This indicates + ► - + · ·

Figure 1

Function of indicators

Note: The Ball valve comes along with the product as standard accessories.



Note: Filters may require replacement before Filter change indications, as filter replacement, as filter replacement depends on feed water conditions (Refer page 14).

. O all A. U. Smith Lustomer Lare Lentre to replace the filters and UV lamp.

blinking and the unit stops functioning. When filters and UV lamp life * reaches its end, filter change indicator keeps on reaching its end time.

Filter change indicator starts blinking indicating that the filter shares indicator starts binking indicating indicating indicators. This indicates that the filters and UV lamp needs to be replaced. Filter change indicator

NOTICE

indicator. Call A. O. Smith Customer Care Centre if you notice continuous blinking of UV lamp AOTICE

NOTICE

This indicates when UV lamp is not functioning. VV lamp indicator

Call A. O. Smith Customer Care Centre if you notice continuuus blinking of Tank full indicator and Power ON indicator.

This indicates that the Water Purifier tank is full.

Tank full indicator

Red Line Mark are for Folding. Not to be Printed



55 Technology: In A. O. Smith Water Purifier passes through Sediment filter + Line Sediment filter + Carbon block + UV lamp + UF (Ultra Fine) filter Purity through 5 Stage UV Purification

Digital display for simple and intelligent display of information.

TrelA Stid VU

Velqsi**O** letipi**O**







Vgolondoalt Technology







key Features



For filters and UV change.









POWER

0



EXPERT SERVICE

User Manual

3

1800-103-2468/1860-500-2468

Monday to Friday: 9 a.m. to 8 p.m.

Saturday & Sunday: 9 a.m. to 6 p.m.

For calls registered at A. O. Smith call centre before 4 p.m. only. Available only in selected cities. For more details, please call our Customer Care Centre or log on to www.aosmithindia.com

+91 99410 32468 (Whats App) or aosmithcs@aosmithindia.com



Water Purifiers **X**2

		ल
Switch OFF the Water Purifier and call Customer Care Centre.	Inlet solenoid valve error.	Power ON and Tank full LED indicator blinks continuously
Check feed water supply to the purifier. If problem still persists, switch OFF the Water Purifier and call Customer Care Centre.	Low pressure alarm is triggered indicating that pressure is not in the required range.	Power ON LED indicator blinks continuously o
Call Customer Care Centre for filters replacement.	Filters may be clogged or bamaged.	
.əvlev lled\qet ədt nəqO	Check whether the tap/ ball valve is closed.	Decreased flow of purified water
Call Customer Care Centre.	Has the raw water quality Changed?	
Call Customer Care Centre for filters/UV lamp replacement.	Filters/UV lam may require replacement.	
Drain the stored water from the storage tank through faucet.	Has the purified water been stored in the tank for long time?	Ster taster die Greef taste
solution	(s)əsuɛJ əldisso٩	Problems
Your A.O. Smith X.2 Water Purifier may not function at its desired capability if used incorrectly. This may not necessarily mean that the product is faulty. For instances like these, please follow the steps given below to troubleshoot the problem without the help from a certified technician. If the problem still persists, please call Customer Care Centre immediately.		

٦٢

.89	72-005-0981/8977-201-0081	oN əreC rəmotsu Clare Vo
Switch OFF the Water Purifier and call Customer Care Centre filters and UV Iamp replacement.	Filters and VV lamp life ends.	Filter change LED blinks and unit is not functioning.
Switch OFF the Water Purifier and call Customer Care Centre filters and UV Iamp replacement.	Filters and UV lamp life is shout to end.	Filter change LED blinks and unit is functioning.
Switch OFF the Water Purifier and call Customer Care Centre.	.910 isî qmsi VU	UV lamp LED blinks continuusiy and unit is not functioning.
Switch OFF the Water Purifier and call Customer Care Centre.	Battery error.	All LED blinks continuously

6

NETER © TDS

Recommended input Feed water quality for the optimum performance of your product

μ


the feed line. If the presence co pay a process of pairs income to be installed. Ensure you buy them from A. O. Smith Company Authorised Service Technician. ! **||** *

zechnical Specificars		
ləbol	Х2	
(W x Q x H) snoisnemiQ four	mm 085 x mm 092 x mm 09 1	
Jet Weight	6.6 kgs (approx.)	
toss Weight	8.9 kgs (approx.)	
torage tank capacity	S انټدوه (approx.)	
urification technology	γροίοπλ ο Σ Ο	
s Stage Purifying Technology	Sediment filter + Fine Sediment filter + Carbon block + UV and + UF (Ultra filter	
Asterial of construction for plastic parts	Food safe, non-toxic, engineering grade plastics	
epstloV tuqu	zH 02 ,DAV 005 – 02 f	
ower rating (Max)	28 Watts	
gniteA sting	isq 05 of isq 2	
Power Rating Power Rating	۲۱ Watts	
nput water temperature	2°24 of 2°2	
If input pressure exceeds 30 psi, a pressure reducing valve needs to be installed at		

٥١



6 srugi7 (Refer page Make sure that the feed water is tested before installation. Do not install the product if the TDS and Hardness are more than that prescribed in the recommended feed water conditions (Beher more al)





∑ ∋rugi7 .thtilnur

Power plug must be used with a 230 V outlet. It is recommended to connect the product to the power supply only with the plug that is provided with the purg with wet hands to avoid electrical shock.

Even though this product is designed keeping highest safety standards in mind, there are certain Do's and Dont's which need to be followed while using this product. Ytəfe2 lszirtzəl3

Safety Precautions

Ŧ

Install the product away from direct

P

Ð

NOITUA

Product should be installed only by A. O. Smith Company Authorised Service Technician. Do not open the purifier for cleaning the filters/UV lamp* or for any part replacements. This must be done part replacements. This must be done Service Technician.


Figure 8 2. Switch ON the power supply. Figure 9 Turn ON the water connection through the ball valve.

3. To dispense water from the storage tank, push and hold the water faucet lever.

esu ot woH

Figure 10

*Do not open UV housing as UV rays will be harmful to the human beings. This must be done only by A. O. Smith Company Authorised Service Technician. ЭИІИЯАЖ 🗘




8

120A - 300V Figure 3

Electrical Diagram

VIdm922A


Water flow







Troubleshooting






L







Discard the first cycle of pure water, before you start using it for consumption.
Make sure to discard the water in the storage tank if you have not used the purifier for more than 2 days.

NOTICE

(H) mm 792 x (W) mm 024 :9zi2 9bi2 fron7