

Frequently Asked Questions

1.How to Connect Aavante Bar 1580 via Bluetooth?

- Ans Long Press Pair Button on your Remote and you will see BT on your Soundbar.
- On your phone search for boAt Aavnate 1580 and connect.

2. How to change the mode of Connection ?

- Ans Press Input to enter AUX/USB/Bluetooth/Optical selection Mode

3. How to Play via USB?

- Ans For USB it will Play directly upon connection of a USB drive.

4.What if the in-built controls are not working ?

- Check if the controls do not work while connected to another device
- Check if the device is in aux mode because the buttons will not work in aux mode
- Check if the media player being used supports such controls and if they controls do not function on call or other media players
- Check if the controls have been physically damaged or exposed to any hazards

5. The Remote control is not working ?

- Check if the controls do not work while connected to another device
- Check if the device is in aux mode because the remote buttons will not work in aux mode
- Check if the media player being used supports such controls and if they controls do not function on call or other media players
- Check if the remote control has been physically damaged or exposed to any hazards
- Before you press any playback control button, first select the correct source.
- Reduce the distance between the remote control and the unit.
- Insert the battery with its polarities (+/-) aligned as indicated.
- Check that the batteries in the remote are functional and of the correct type, try to replace the battery.
- Aim the remote control directly at the sensor on the front of the unit.

6. What if there is no sound output ?

- Ans Check to see if the device has been properly connected, i.e. the jack is properly inserted into the device for aux, properly connected with the HDMI cable from unit's **HDMI (ARC)** slot to the HDMI (ARC) slot on your ARC compatible TV, check if the protective cap of the **OPTICAL** socket is removed, then connect an OPTICAL cable to the TV's **OPTICAL OUT** socket and the **OPTICAL** socket on the unit, the USB that is connected is functional or if it is connected by Bluetooth then it is paired properly and the blue light is not blinking to indicate it is properly paired in Bluetooth mode.
- When using either of the Digital inputs, if there is no audio, try setting the TV output to PCM or connect directly to your Blu-ray/other source, some TVs do not pass through digital audio, check the TV manual for details.
- Your TV may be set to variable audio output. Confirm that the audio output setting is set to FIXED or STANDARD, not VARIABLE. Consult your TV's user manual for more detailed information.
- Check if the device has been properly connected to the power socket and if the problem occurs on all modes of playback. If connected to the TV, ensure that the connections are secure, the TV supports the playback mode and the volume is set properly on the TV.
- Check if the device was not subject to any mishandling, or exposed to direct sunlight or hazards like fire.

7. The device doesn't turn on ?

- **Ans** Check if the AAVANTE Bar and the subwoofer are plugged in properly to the power source and turned on using the button on the soundbar or the remote.
- Check if there are any loose wirings.
- Turn off the power switch and wait for a few minutes and try again.

8. The sound is distorted/low volume/low bass/low quality.

- **Ans** Check if connected device does not have any equalizer settings applied.
- Check if the problem still occurs if the device is moved closer and all obstacles in the middle are removed.
- Check if the distortion or quality lowers at all volumes or only at high volumes.
- Check to Check different media players and different devices and if the distortion happens on all devices or only on specific ones.
- Check if the problem occurs when connected to different power sockets.

9. The subwoofer fails to Functions.

- Ans Check that both units are plugged in properly and turned on.
- Check that the boAt Aavante Bar 1580 is not in standby mode.
- Make sure that the Subwoofer is connected properly on the port on the back side of the Soundbars.
- There are no issues with the wires.

10. Does it have FM ?

Ans : No, it doesn't have in-built FM.

11. Does it Support Alexa?

Ans: No, it doesn't support Alexa

12. How do you connect it with Amazon Firestick?

Ans: The Amazon Firestick will not connect to the Soundbar. The Sound Bar and the Amazon Firestick would connect separately to the TV.

13. Does it support Dolby Audio?

Ans: No it doesn't support Dolby Audio.

14. Is installation provided by the seller ?

Ans: Installation Is not provided by the seller.

15. Does it work with Non Smart TVs / TVs without Bluetooth ?

Ans: Yes it does using HDMI (Arc)/ Optical/ Aux.

16. Does the Subwoofer have separate controls / Can it be used Separately ?

Ans: No it can be use with Soundbars only

17.Does it work on devices other than TV ?

Ans: It does Work with devices with Bluetooth or Aux connectivity.

18. Is it Wall mountable ?

Ans: Yes it is Mountable.

19. Does it come with a Remote ?

Ans : Yes it does.